

**INSTRUCTIONS FOR INSTALLING
WEBFLEX USB COMMUNICATIONS DRIVER
FOR WINDOWS XP**

*** DO NOT INSERT YOUR CD UNTIL ASKED TO DO SO ***

1. POWER UP WEBFLEX AND PC/LAPTOP
2. CONNECT THE SUPPLIED USB CABLE BETWEEN THE TWO
3. FOUND NEW HARDWARE "RNDIS/Ethernet Gadget"
4. CHECK OR
5. CLICK OR
6. CHECK
CLICK
CHECK
CHECK

INSERT CD SUPPLIED IN CD ROM DRIVE

- CLICK
CLICK
CLICK

NB* REPEAT THIS PROCEDURE FOR EACH USB PORT ON YOUR COMPUTER THAT MAY BE USED TO CONNECT TO WEBFLEX.

- CLICK then
CLICK
RIGHT CLICK ON THE NEW
CLICK
HIGHLIGHT
CLICK
CHECK
IN THE IP ADDRESS BOX TYPE
IN THE SUBNET MASK BOX TYPE
CLICK
CLICK

OPEN THE INTERNET EXPLORER AND TYPE 199.199.199.2 IN THE ADDRESS BAR. FROM THIS POINT ON, CONNECTING THE USB LEAD AND TYPING THIS ADDRESS (FAVOURITES/BOOKMARKS) WILL CONNECT YOU TO YOUR CONTROLLER.

